



▀ WIRE NUTS

▣ QUICK SLIDE TERMINAL

\* EXCHANGE THESE WIRES TO CHANGE MOTOR DIRECTION

MOTOR CONNECTIONS (AT MOTOR) FOR HI-TIDE LIFTS.

NOTE: CONNECTIONS AT MOTORS ARE THE SAME FOR REMOTE CONTROLS AND SWITCHES

HI-TIDE MISC. MOTOR  
WIRING DIAGRAM

DRAWN BY: R. HYDE SCALE: NTS 10/1/12



BOATLIFTS AND MARINE PRODUCTS  
4050 SELVITZ ROAD  
FORT PIERCE, FL 34981  
1-800-544-0735 www.hi-tide.com